



# **Application Note**

## **AN\_420**

### **FT\_App\_Keyboard**

**Version 1.1**

**Issue Date: 2018-01-05**

This application note describes the operation of the Keyboard Demo Application running on an FT81X. The Keyboard example demonstrates how fast and easy it is to use FT81X commands to construct a fully functional keypad GUI.

Use of Bridgetek devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold Bridgetek harmless from any and all damages, claims, suits or expense resulting from such use.

**Bridgetek Pte Ltd (BRTChip)**  
178 Paya Lebar Road, #07-03, Singapore 409030  
Tel: +65 6547 4827 Fax: +65 6841 6071  
Web Site: <http://www.brtchip.com>  
Copyright © Bridgetek Pte Ltd

## **Table of Contents**

<b>1</b>	<b>Introduction.....</b>	<b>3</b>
1.1	Overview .....	3
1.2	Scope .....	3
<b>2</b>	<b>Keyboard Overview .....</b>	<b>4</b>
<b>3</b>	<b>Design Flow .....</b>	<b>5</b>
3.1	Initialisation.....	5
3.2	Application Flow .....	6
<b>4</b>	<b>Description.....</b>	<b>7</b>
4.1	Application Start Screen .....	7
4.2	Keypad Function.....	7
<b>5</b>	<b>Running the Demonstration Code.....</b>	<b>9</b>
<b>6</b>	<b>Contact Information.....</b>	<b>10</b>
	<b>Appendix A– References .....</b>	<b>11</b>
	Document References .....	11
	Acronyms and Abbreviations .....	11
	<b>Appendix B – List of Figures &amp; Tables .....</b>	<b>12</b>
	List of Figures .....	12
	List of Tables .....	12
	<b>Appendix C– Revision History .....</b>	<b>13</b>

# 1 Introduction

This document describes the operation of the Keyboard Demo Application running on an FT81X. The example demonstrates how fast and easily a fully functional keypad GUI can be constructed using FT81X commands. Please also refer to the sample code project provided on the Bridgetek website which demonstrates all the features of FT81X - <http://brtchip.com/eve/>.

## 1.1 Overview

This application demonstrates the coprocessor command and touch tracking features of the FT81X.

The example demonstrates that in addition to providing an attractive graphical user interface for an application, the FT81X's tagging features can be used to construct effective, fully interactive GUI operations rapidly.

## 1.2 Scope

This document can be used by designers to develop GUI applications on a hardware setup that use an FT81X interfaced to a SPI host. The SPI host can be a PC running Visual Studio (C++) with a C232HM cable or an FT900.

The document covers the following topics:


- Brief overview of the Keypad demonstration
- Flow of the program including the FT81X initialisation and keypad code
- Description of the keypad function within the application
- Running the demonstration program

Additional documentation can be found at <http://brtchip.com/eve/>.

## 2 Keyboard Overview

This example demonstrates keyboard development capabilities of the FT81X.

The application supports a multiline editor area with an alphanumeric keyboard. The layout with numbers also provides some special character buttons. The button labelled "a^" acts like a CAPS LOCK key and switches key entry to capital (block) letters. The button labelled "12\*" switches the keyboard layout to numbers and some special characters. The "<" backspace key, "Clear" key and "Space" spacebar key are all available in both CAPS LOCK and numeric entry mode. Figures 2.1 and 2.2 show the keyboard layout in alphabets and numbers.



**Figure 2.1 The Keyboard example application**



**Figure 2.2 Keyboard example number layout**

This application runs on a host processor which triggers commands for the FT81X over SPI communication. The host processor may be a PC (through an MSVC project application) which uses USB-to-SPI bridge chip from FTDI Chip (e.g. FT232H / FT4222H) or an FT900 which establishes a connection to FT81X over SPI.

The application uses FT81X commands, namely, CMD\_KEYS and CMD\_BUTTON together with touch controller registers to create this keyboard.


## 3 Design Flow

### 3.1 Initialisation

Every EVE design follows the same basic principles as highlighted in Figure 3.1. After configuring the SPI Host itself (such as the PC through the C232HM cable, or an MCU), the application will wake up the FT81X and write to the registers in the FT81X to configure its display, touch and audio settings etc. It then writes an initial display list to clear the screen.


The main application can then create display lists to draw the actual application screens, in this case, the keyboard screen. In essence, there will be two lists; the active list and the edited list which are continually swapped to update the display. Each screen can be created by either writing a display list to the RAM\_DL memory in the FT81X or by writing a series of commands to the Co-Processor FIFO in the FT81X (in which case, the Co-Processor will create a display list in RAM\_DL based on the commands).

Header files map the pseudo code of the design file of the display list to the FT81X instruction set, which is sent as the data of the SPI packet (typically <1KB). As a result, with EVE's object oriented approach, the FT81X is operating as an SPI peripheral while providing full display, audio, and touch capabilities.



**Figure 3.1 Generic EVE Design Flow**

## 3.2 Application Flow



**Figure 3.2 Application Flowchart**

## 4 Description

### 4.1 Application Start Screen

Refer to [AN\\_391 EVE Platform Guide](#) for information pertaining to platform setup and the necessary development environment.

Upon setting up the platform, the application start screen is displayed –



**Figure 4.1 Start screen**

### 4.2 Keypad Function

This is the main function in which the application will now remain. After initialization, the code will run in a continuous loop where it will perform the following functions.

- Check the Tag registers and determine the keypress
- Draw the background, and clear an area with the scissor functions
- Draw those buttons common for both number and alphabet keypad layout with labels and tags
- Draw the keypad layout by determining whether number keypad or alphabet with labels and set tags
- Display the key pressed

Following are the crucial global variables and macros which are controlling the keypad operation.

1. `uint8_t Read_Keypad()` is the function to read a keypress. Debounce logic is also included in it. The registers `REG_TOUCH_TAG` and `REG_TOUCH_RAW_XY` are used to detect the key presses.
2. `void Notepad(void)` is the function which holds the entire keyboard functioning logic.
3. The multiline editor area content is held in a global variable called Buffer which is a structure type as shown below.

```
struct Notepad_buffer
{
    char8_t *temp;
    char8_t notepad[MAX_LINES][80];
}Buffer;
```

4. The following variable Flag maintains the information about the keypad layout to be drawn.

```
struct
{
    uint8_t Key_Detect :1;
    uint8_t Caps :1;
    uint8_t Numeric : 1;
    uint8_t Exit : 1;
}Flag;
```

5. To display the next character input position on the editor area, the current character width is read from the font metric block and added to the current display position thereby computing the next character input position.

```
Disp_pos += Gpu_Rom_Font_WH(Buffer.notepad[Line][0],Font); // Update
the Disp_Pos
noofchars+=1;
```

6. The detected key press is processed in an if/else block based on whether the key pressed is a special function or normal character/number key press. The following special functions are defined for this purpose.

```
#define SPECIAL_FUN    251
#define BACK_SPACE    251 // Back space
#define CAPS_LOCK     252 // Caps Lock
#define NUMBER_LOCK   253 // Number Lock
#define BACK          254 // Exit
```

7. The TAG display list command along with CMD\_BUTTON and CMD\_KEYS co-processor commands are used to draw the complete keyboard. The pressed keys are displayed in editor area using CMD\_TEXT co-processor command.



## 5 Running the Demonstration Code


This package has project solutions to build and execute the keypad application using the following IDEs.

- <...>\App\_Keyboard\Project\Msvc\ has a Visual Studio (C++) project in which a PC is used as an SPI host to send FT81X commands. This setup requires a USB-to-SPI bridge chip to establish communication from PC to FT81X. The development modules like ME812AU and ME813AU have this bridge chip mounted on the PCB.
- <...>\App\_Keyboard\Project\FT90x has an Eclipse project in which an FT900 is used as the SPI host. The FT90x Toolchain can be downloaded from Bridgetek website.
- <...>\App\_Keyboard\Project\Msvc\_Emulator has a Visual Studio (C++) project for an Emulated version of the FT81X. This project doesn't need any hardware to launch the application.

The user of this application needs to open the project in one of the IDE listed above, followed by enabling the platform macros in the Platform.h header file. Depending on the underlying hardware, one of the following platform configurations must be chosen.

```
//#define VM800B43_50 (1)
//#define VM800B35 (1)
//#define VM801B43_50 (1)
//#define VM810C50 (1)
#define ME812AU_WH50R (1)
//#define ME813AU_WH50C (1)
```

Now the project should be able to build and run.



**Figure 5.1 - Keyboard**

## 6 Contact Information

### Head Quarters – Singapore

Bridgetek Pte Ltd  
178 Paya Lebar Road, #07-03  
Singapore 409030  
Tel: +65 6547 4827  
Fax: +65 6841 6071

E-mail (Sales) [sales.apac@brtchip.com](mailto:sales.apac@brtchip.com)  
E-mail (Support) [support.apac@brtchip.com](mailto:support.apac@brtchip.com)

### Branch Office – Taipei, Taiwan

Bridgetek Pte Ltd, Taiwan Branch  
2 Floor, No. 516, Sec. 1, Nei Hu Road, Nei Hu District  
Taipei 114  
Taiwan, R.O.C.  
Tel: +886 (2) 8797 5691  
Fax: +886 (2) 8751 9737

E-mail (Sales) [sales.apac@brtchip.com](mailto:sales.apac@brtchip.com)  
E-mail (Support) [support.apac@brtchip.com](mailto:support.apac@brtchip.com)

### Branch Office - Glasgow, United Kingdom

Bridgetek Pte. Ltd.  
Unit 1, 2 Seaward Place, Centurion Business Park  
Glasgow G41 1HH  
United Kingdom  
Tel: +44 (0) 141 429 2777  
Fax: +44 (0) 141 429 2758

E-mail (Sales) [sales.emea@brtchip.com](mailto:sales.emea@brtchip.com)  
E-mail (Support) [support.emea@brtchip.com](mailto:support.emea@brtchip.com)

### Branch Office – Vietnam

Bridgetek VietNam Company Limited  
Lutaco Tower Building, 5th Floor, 173A Nguyen Van  
Troj,  
Ward 11, Phu Nhuan District,  
Ho Chi Minh City, Vietnam  
Tel : 08 38453222  
Fax : 08 38455222

E-mail (Sales) [sales.apac@brtchip.com](mailto:sales.apac@brtchip.com)  
E-mail (Support) [support.apac@brtchip.com](mailto:support.apac@brtchip.com)

### Web Site

<http://brtchip.com/>

### Distributor and Sales Representatives

Please visit the Sales Network page of the [Bridgetek Web site](#) for the contact details of our distributor(s) and sales representative(s) in your country.

System and equipment manufacturers and designers are responsible to ensure that their systems, and any Bridgetek Pte Ltd (BRTChip) devices incorporated in their systems, meet all applicable safety, regulatory and system-level performance requirements. All application-related information in this document (including application descriptions, suggested Bridgetek devices and other materials) is provided for reference only. While Bridgetek has taken care to assure it is accurate, this information is subject to customer confirmation, and Bridgetek disclaims all liability for system designs and for any applications assistance provided by Bridgetek. Use of Bridgetek devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify and hold harmless Bridgetek from any and all damages, claims, suits or expense resulting from such use. This document is subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Neither the whole nor any part of the information contained in, or the product described in this document, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. Bridgetek Pte Ltd, 178 Paya Lebar Road, #07-03, Singapore 409030. Singapore Registered Company Number: 201542387H.

## Appendix A– References

### Document References

- [Datasheet for VM800C](#)
- [Datasheet for VM800B](#)
- [AN\\_391 EVE Platform Guide](#)
- [FT8XX Series Programmer Guide](#)
- [FT800 Embedded Video Engine Datasheet FT\\_000792](#)

### Acronyms and Abbreviations

Terms	Description
Arduino Pro	The open source platform variety based on ATMEL's ATMEGA chipset
EVE	Embedded Video Engine
SPI	Serial Peripheral Interface
UI	User Interface
USB	Universal Serial Bus

---

## Appendix B – List of Figures & Tables

### List of Figures

Figure 2.1 The Keyboard example application .....	4
Figure 2.2 Keyboard example number layout.....	4
Figure 3.1 Generic EVE Design Flow .....	5
Figure 3.2 Application Flowchart .....	6
Figure 4.1 Start screen .....	7
Figure 5.1 - Keyboard.....	9

### List of Tables

NA

---

## Appendix C– Revision History

Document Title: AN\_420 FT\_App\_Keyboard  
Document Reference No.: BRT\_000054  
Clearance No.: BRT#048  
Product Page: <http://brtchip.com/product/>  
Document Feedback: [Send Feedback](#)

Revision	Changes	Date
1.0	Initial release	2016-11-08
1.1	Document migrated from Dual Branding to BRT (Updated company logo; copyright info; contact information; hyperlinks) Updated source code and pictures	2018-01-05